



**Tips** -Hold the green button in while you're filming. You can film about 4 minutes - then upload clips and film more. Check the sound and resolution. Delete the clips you don't want before uploading.



**Edit button**, works with video clips.

The **camera button** will be on when you're uploading your movie clips.

**Share button**, print, watch or make clips into a screen saver.

If you get stuck ...click on the **help** button and **search** for solutions.





